Separation Processes ChE 4M3





kevin.dunn@mcmaster.ca http://learnche.mcmaster.ca/4M3

Overall revision number: 149 (November 2012)

# Copyright, sharing, and attribution notice

This work is licensed under the Creative Commons Attribution-ShareAlike 3.0 Unported License. To view a copy of this license, please visit http://creativecommons.org/licenses/by-sa/3.0/

This license allows you:

- to share to copy, distribute and transmit the work
- to adapt but you must distribute the new result under the same or similar license to this one
- commercialize you <u>are allowed</u> to use this work for commercial purposes
- attribution but you must attribute the work as follows:
  - "Portions of this work are the copyright of Kevin Dunn", or
  - "This work is the copyright of Kevin Dunn"

(when used without modification)

We appreciate:

- if you let us know about any errors in the slides
- any suggestions to improve the notes

All of the above can be done by writing to

#### kevin.dunn@mcmaster.ca

If reporting errors/updates, please quote the current revision number: 149

### Administrative

- Assignment 5 is posted (3 questions so far); questions 4 and 5 posted by Tuesday afternoon
- Assignment 5 is due in the Chem Eng drop box by Monday, 03 December, at 16:00, or earlier.
- Assignment 4 will be available for pick up on Thursday and Friday.
- Midterm will be available to pick up Tuesday, Thursday, Friday.
- Please fill in a course evaluation: https://evals.mcmaster.ca
- Confused about grades? There's a grading spreadsheet online
  - Please do not use averages and symbols calculated by Avenue
- Course review on Friday, 30 November.

# Background

We consider drying of solid products here.

- Remove liquid phase from solid phase by an ESA = thermal energy
- It is the final separating step in many processes
  - pharmaceuticals
  - foods
  - crops, grains and cereal products
  - Iumber, pulp and paper products
  - catalysts, fine chemicals
  - detergents

Why dry?

- packaging dry product is much easier than moist/wet product
- reduces weight for shipping
- preserves product from bacterial growth
- stabilizes flavour and prolongs shelf-life in foods
- provides desirable properties: e.g. flowability, crispiness
- reduces corrosion: the "corrosion triangle": removes 1 of the 3

### The nature of water in solid material



Material, when exposed to air with a certain humidity, will reach equilibrium with that air.

#### 1. Bound moisture

- adsorbed into material's capillaries and surfaces
- or in cell walls of material
- its vapour pressure is below water's partial pressure at this T

#### 2. Free moisture

 water in excess of the above equilibrium water

# Drying: the heat and mass transfer view points

#### Both heat and mass transfer occur simultaneously

#### Mass transfer

- Bring liquid from interior of product to surface
- Vapourization of liquid at/near the surface
- Transport of vapour into the bulk gas phase

**Heat transfer** from bulk gas phase to solid phase:

- portion of it used to vapourize the liquid (latent heat)
- portion remains in the solid as (sensible heat)

Key point: heat to vapourize the liquid is provided by the air stream



Wikipedia File:Phase\_diagram\_of\_water.svg

- Partial pressure, recall, is the pressure due to water vapour in the water-air mixture
- Vapour pressure, is the pressure exerted by (molecules of liquid water in the solid) on the gas phase in order to escape into the gas [a measure of volatility]

Moisture evaporates from a wet solid only when its vapour pressure exceeds the partial pressure

Vapour pressure can be raised by heating the wet solid

### Psychrometric chart



Geankoplis, p568; multiple internet sources have this chart digitized

- Dry bulb temperature: or just T = "temperature" (nothing new here)
  - the horizontal axis on the psychrometric chart
- Humidity =  $\psi$  = mass of water vapour per kilogram of dry air

  - units are  $\left[\frac{\text{kg water vapour}}{\text{kg dry air}}\right]$
  - called H in many textbooks; always confused with enthalpy; so we will use  $\psi$
  - units do not cancel. i.e. not dimensionless
  - the vertical axis on the psychrometric chart
- Maximum amount of water air can hold at a given T:
  - $\psi_{S} =$  saturation humidity
  - move up vertically to 100% humidity
- Percentage humidity =  $\frac{\psi}{\frac{\psi}{2}} \times 100$
- Partial pressure we said is the pressure due to water vapour in the water-air mixture

► 
$$\psi = \frac{\text{mass of water vapour}}{\text{mass of dry air}} = \frac{18.02}{28.97} \frac{p_A}{P - p_A}$$
  
►  $p_A = \text{partial pressure of water in the air}$ 

 $\triangleright$  P = total pressure = 101.325 kPa in this psychrometric chart 11

Dew point: the temperature to which you must cool the air/vapour mixture to just obtain saturation (100% humidity), i.e. condensation just starts to occur.



**Example:** Air at  $65^{\circ}$ C and 10% humidity has a dew point temperature of  $25^{\circ}$ C. This parcel of air contains 0.021 kg of water per kilogram of dry air.

Humid heat: amount of energy to raise 1kg of air and the water vapour it contains by 1°C

 $c_{S} = 1.005 + 1.88\psi$ 

### Administrative

#### Assignment 5

- Due on Monday, 03 December, at 16:00 in Chem Eng dropbox
- Or due electronically
- Update to question 3.3.3 (or question 3.3(c))
  - Solvent flow, S = 27.5 kg/hr, not 15 kg/hr

Please fill in a course evaluation:

https://evals.mcmaster.ca

Currently 36% of the class have filled it in



### Terminology: adiabatic saturation

Consider a stream of air at temperature T and humidity  $\psi$ . It contacts fine water droplets long enough to reach equilibrium. The leaving gas has temperature  $T_S$  and humidity  $\psi_S$ .



We expect outlet gas:  $T_S < T$  and  $\psi_S > \psi$ 

The energy to evaporate liquid water into the leaving air stream comes from the air.

### Terminology: adiabatic saturation

Quantify it: do an enthalpy balance at  $T_{ref} = T_S$  (i.e. disregard water)



Enthalpy of vapour phase entering:

$$c_{S}(T-T_{S})+(\psi)(\Delta H_{vap})$$

Enthalpy of vapour phase leaving:

$$c_S (T_S - T_S) + (\psi_S)(\Delta H_{vap})$$

$$\frac{y-\text{axis change}}{x-\text{axis change}} = \frac{\psi - \psi_S}{T - T_S} = -\frac{c_S}{\Delta H_{\text{vap}}} = -\frac{1.005 + 1.88\psi}{\Delta H_{\text{vap}}}$$
  
These are the diagonal sloped lines on the psychrometric chart: adiabatic saturation curves.

### Adiabatic saturation temperature



### Exercise

An air stream at  $70^{\circ}$ C and carrying 0.055 kg water per kg dry air is adiabatically contacted with liquid water until it reaches equilibrium. The process is continuous and operating at steady-state. Air feed is 1 kg dry air per minute.

- 1. What is the percentage humidity of the incoming air stream? [20%]
- 2. What is the percentage humidity of the air stream leaving? [100%]
- 3. What is the humidity [mass/mass] of the air stream leaving?  $[\rm 66g/kg]$
- 4. What is the temperature of the air stream leaving? [42.5°C]
- 5. If the contacting takes place in a unit shown below, what is the mass of inlet make-up water required at steady-state operation?



### Wet-bulb temperature



Wikipedia: http://en.wikipedia.org/wiki/Wet-bulb\_temperature]

- Calculated similar to adiabatic saturation temperature, except the gas temperature and humidity do not change
- Surprisingly, the slope coefficient is very close to adiabatic slope coefficient
- This is only true for water vapour

### Humid volume

Equivalent to the inverse density  $1/\rho$  of moist air.

Derived from the ideal-gas law and simplified here:

$$v_{H} = \left[2.83 imes 10^{-3} + 4.56 imes 10^{-3} \psi 
ight] {\ T} ~~ {{
m m}^{3}\over {
m kg moist air}}$$

- $\blacktriangleright \ \psi$  is humidity in kg water per kg dry air
- ► *T* is the temperature in K

For example, 350K and  $\psi=$  0.026 kg/kg, then

$$v_{H} = \left[2.83 imes 10^{-3} + 4.56 imes 10^{-3} (0.026)
ight] (350) = 1.03 \, rac{ ext{m}^{3}}{ ext{kg moist air}}$$

# Drying profiles

Solids drying is phenomenally complex for different materials. Observe it experimentally and plot it:



- A  $\rightarrow$  B: initial phase as solid heats up
- $B \rightarrow C$ : constant-rate drying
- $C \rightarrow D$ : first falling-rate drying
- $D \rightarrow end$ : second falling-rate drying

# Drying profiles

- Water flux =  $\frac{\text{mass of water removed}}{(\text{time})(\text{area})} = -\frac{m_s}{A}\frac{dX}{dt} = \frac{1}{A}\frac{d(m_w)}{dt}$
- X = mass of water remaining per mass dry solid
- A = surface area of solid exposed
- ▶ m<sub>s</sub> = mass of dry solid
- $m_w =$  mass of water evaporated out of solid

We are most interested in the constant drying-rate period:

- rate-limiting step: mass transfer through boundary layer on the solid surface
- the solid is able to provide water to the surface a fast rate

### Heat transfer during constant drying

- In constant-rate drying region the wet surface continually supplies moisture.
- All the heat provided is taken up to evaporate liquid

(Water flux)( $\Delta H_{vap}$ ) = Heat flux  $\frac{1}{A}\frac{d(m_w)}{dt} \times \Delta H_{\rm vap} = \frac{\text{driving force}}{\text{resistance}} = \frac{h(T_{\rm air} - T_{\rm solid surface})}{1}$  $\frac{d(m_w)}{dt} = \frac{hA(T_{db} - T_{wb})}{\Lambda H_{wb}}$  $\int_{m_{wav}}^{m_{w,f}} d(m_w) = \Delta M_{water} = \int_{t_0}^{t_f} \frac{hA(T_{db} - T_{wb})}{\Delta H_{vap}} dt$ 

$$\frac{(\Delta M_{\rm water})(\Delta H_{\rm vap})}{hA(T_{\rm db}-T_{\rm wb})} = \text{time to remove } \Delta M_{\rm water}$$

### Some heat-transfer correlations

- In constant-rate drying region the wet surface continually supplies moisture
- Heat-transfer coefficients derived that are independent of solid type!
- 1. Parallel flow to surface:
  - Air between 45 to 150°C
  - $G = 2\,450$  to 29 300 kg.hr<sup>-1</sup>.m<sup>-2</sup>
  - This corresponds to a velocity of v = 0.61 to 7.6m.s<sup>-1</sup>
  - $G = 3\,600\,\rho v_{\text{avg}}$  where v and  $\rho$  are in SI units
  - ▶  $h = 0.0204G^{0.8}$  [W.m<sup>-2</sup>.K<sup>-1</sup>]  $\leftarrow$  awkward units for G!
- 2. Perpendicular flow (impingement)
  - Air between 45 to 150°C
  - $G = 3\,900$  to  $19\,500 \,\text{kg.hr}^{-1}.\text{m}^{-2}$
  - This corresponds to a velocity of v = 0.9 to 4.6m.s<sup>-1</sup>

• 
$$h = 1.17G^{0.37}$$
 [W.m<sup>-2</sup>.K<sup>-1</sup>]

See textbooks for h when using pelletized solids (e.g packed bed)

### Filter cake drying example





[Flickr, CC BY 2.0]

[Flickr, CC BY 2.0]

Consider 100kg of cake, discharged at 30% moisture (wet basis). Air to dry the cake at  $75^{\circ}$ C is used, 10% relative humidity, with a velocity of 4 m/s parallel to the solids, which are  $2 \text{ m}^2$ . The aim is to achieve a 10% (dry basis) cake which can be milled and packaged.

Estimate the drying time.

# Space for calculations

### Filter cake drying example

- 1. What is the humidity of the incoming air stream? [ $\psi = 0.04 \text{ kg}$ water/kg dry air]
- 2. What is the wet-bulb temperature of this air stream?  $[T_{wb} \approx 41.3^{\circ}\text{C}]$
- 3. What is the humid volume of the drying air stream? [T = 348K,  $v_H = 1.048m^3/kg$ ]
- 4. Estimate the heat transfer coefficient.
  - $G = 3600 \rho v_{avg} = 3600(1.048)^{-1} \times 4 = \frac{13740 \text{ kg.hr}^{-1} \text{ m}^{-2}}{13740 \text{ kg.hr}^{-1} \text{ m}^{-2}}$
  - $h = 0.0204(13740)^{0.8} = h = 41.7 \text{ W.m}^{-2}.\text{K}^{-1}$
- 5. Substitute into the constant-drying rate expression to find:

• drying time = 
$$\frac{(\Delta M_{water})(\Delta H_{vap})}{hA(T_{db} - T_{wb})} = \frac{(29.3)(2401 \times 1000)}{(41.7)(2)(75 - 41.3)} = 6.95 \text{ hrs}$$

- We need the  $\Delta H_{vap}$  at  $T_{wb}$  (why?) [2401 kJ/kg]
  - 2501 kJ/kg at  $0^{\circ}C$
  - $\blacktriangleright~2260~kJ/kg$  at  $100^{\circ}C$

### Equipment

Multiple dryer types are commercially available:

- each have relative advantages and disadvantages
- our purpose is not to cover their details
- in practice: you would work in consultation with vendors
- ▶ in practice: plenty of trade literature on the topics (SDL !)

Some major distinctions though:

- mode of operation: batch (low volume) vs continuous
- how the heat is provided:
  - direct heat: convective or adiabatic; provides heat and sweeps away moisture
  - indirect heat: non-adiabatic, i.e. by conduction or radiation;
     e.g microwave
- degree of agitation
  - stationary material
  - fluidized or mixed in some way

## How to choose the equipment\*

- Strongly dependent of feed presentation
  - ▶ is it: solid, slurry, paste, flowing powder, filter cake, fibrous, *etc*
- Heating choice: temperature-sensitive if convective heat is directly applied
- Agitation:
  - produce fines (dust hazard) or fragile material
  - good mixing implies good heat distribution
  - stationary product: can form hot-spots in the solid

General choices are between:

- 1. shelf/tray dryers
- 2. continuous tunnels
- 3. rotary dryers
- 4. drums
- 5. spray dryers
- 6. fluidized beds
- \* See Schweitzer; See Perry's

### Some equipment examples

#### Rotating dryer



[Schweitzer, p 4-161 and 4-162]

### Some equipment examples Fluidized bed dryer



- upward flowing air stream (elutriation)
- turbulent mixing: good heat and mass transfer
- uniform solid temperature
- solids are gently treated
- solids are retrieved via gravity and cyclones
- fluidizing air is scrubbed before being vented

### References used (in alphabetical order)

- Geankoplis, "Transport Processes and Separation Process Principles", 4th edition, chapter 09
- ▶ Perry's Chemical Engineers' Handbook, Chapter 12
- Richardson and Harker, "Chemical Engineering, Volume 2", 5th edition, chapter 16
- Schweitzer, "Handbook of Separation Techniques for Chemical Engineers", Chapter 4.10
- Seader, Henly and Roper, "Separation Process Principles", 3rd edition, chapter 18
- Uhlmann's Encyclopedia, "Drying", DOI:10.1002/14356007.b02\_04.pub2